STANDARD BED AND CHAIR MONITOR

The Standard Bed and Chair Monitor is a simple solution for patients who need continual monitoring. Staff can easily move the monitor from one location to another, so a patient can be monitored whether they're in bed, in a chair, or even in the bathroom.



The Nurse Call jack lets you connect the monitor directly to your nurse call system.



The strain relief helps prevent damage to sensor pad cords.

EASE OF USE

- Dedicated button for quick access to volume control
- Recessed On/Off switch
- "Low Battery/Replace Pad", "Alarm", and "In Use" indicator LEDs show status at a glance

FLEXIBILITY

- ▶ Nurse Call Jack allows direct notification to nurse call
- ▶ Bed, chair, and wall mount options are available

DURABILITY

- Strain relief helps prevent damage to the sensor pad cord
- Durable thick plastic casing and impact-resistant rubberized edging reduces replacement/repair costs
- Two year warranty

SPECIFICATIONS

- ≥ Size: 5.3" H x 3.5" W x 1.7" D
- Power Source: 4 AA batteries (included)
- Manufactured to ISO9001, conforms to ANSI/UL standard 1069, certified to CAN/CSA C2.2 #205



COMPATIBLE SENSORS

See reverse





SENSORS

BED AND CHAIR SENSOR PADS

To meet the needs of different patients and situations, Curbell's sensor pads are available in a variety of sizes and styles.

- Larger pad sizes provide more surface area for monitoring restless patients, thus reducing nuisance alarms
- Smaller pad sizes allow for more immediate alarm notification if the patient shifts out of normal position
- ▶ Three usable lifespans:
 - 14 and 30 day pads (white: suitable for hospital patients)
 - One year pads (blue: for long-term patients)
- Two styles: Corded, and Corded Timed





Corded pads are a good choice when you need a simple sensor for your monitors.

 $\label{thm:connectors} The \ break away \ cable \ allows \ connectors \ to \ separate \ under \ strain \ to \ minimize \ cord \ and \ monitor \ damage.$



An internal clock counts down the life of the pad based on actual use (i.e. when the pad is plugged in and pressure is applied to the pad), allowing you to extend the usable period of the pad. The monitor will notify you when to replace the pad.

		Ī	10*	4" (20"
Lifespan	Pad Style	7" x 15" Chair Pads	10" x 15" Chair Pads	4" x 30" Bed Pads	10" x 30" Bed Pads	20" x 30" Bed Pads
14 Day 🔘	Corded (white)	CSP-C14-NC7 (10 pack)	-	CSP-B14-NC4 (10 pack)	-	-
30 Day	Corded (white)	-	CSP-C30-NC10 (10 pack)	CSP-B30-NC4 (10 pack)	-	-
One year 🔘	Corded (blue)	-	CSP-C365-NC10	CSP-B365-NC4	CSP-B365-NC10	-
One year	Corded Timed (blue)	•	CSP-C365-TC10	•	CSP-B365-TC10	CSP-B365-TC20



TOILET SEAT SENSOR

The Toilet Seat Sensor mounts discreetly underneath the toilet seat so that a patient can be monitored without a loss of privacy.




CS-SB2054V
SEAT BELT SENSOR

The Seat Belt Sensor features a Velcro® fastener. In addition to setting off an alarm when unfastened, it also helps keep the patient from sliding down the chair.



CS-FMS-C2448
FLOOR MAT SENSOR

The 24" x 48" Floor Mat Sensor can alert staff if a patient attempts to stand or walk.



CS-FCS-C3668 FLOOR CUSHION SENSOR ◎

The 36" x 68" Floor Cushion Sensor provides extra protection with 2" of padding in case the patient falls while attempting to stand or walk.

ACCESSORIES

		,
Model	Description	Model Number
Bed Mounting Bracket	Adjustable to fit 7/8" to 2 5/8" width headboards and footboards	CSM-BMB
Magnetic Mounting Bracket	Mounts to standard metal door jambs	CSM-MMB
Wall Mounting Bracket	Mounts to the wall with screws or Velcro strips	CSM-WMB
Jumper Cable	This 8' jumper cable connects the monitor to the nurse call system	JU96-295
Replacement Bed Pad Breakaway Cable	80" Breakaway Cable for 30 day and one year corded bed pads	CSP-BCR
Replacement Chair Pad Breakaway Cable	34" Breakaway Cable for 30 day and one year corded bed pads	CSP-CCR