


LOW VOLTAGE CONTROLLER WIRING DIAGRAMS

FOR LC-040 (120 VAC APPLICATIONS) AND LC-050 (240/277 VAC APPLICATIONS)

IMPORTANT:

- Consult the Directions for Use for your low voltage controller for complete installation instructions

Barrier Plates and Conduit Installation



Suggested installation indicated. Consult the National Electrical Code, article 725-54 exceptions 1 and 2A if your installation varies. For additional assistance, call 1-800-235-7500.

Wiring Diagram for One SPST Momentary Switch

Wiring Diagram for Two SPST Momentary Switches

